

# Melrose Ave t-shirt transfers

Use iron-on transfers to create your own fun fashion looks.

## materials

- Melrose Avenue Mix, Match & Layer range of iron on transfers – Soft Transfer, Flocked Iron-On Transfer or Metallic Foil Transfer, Appliqué Patch
- plain t-shirt
- iron
- pins
- pressing cloth

## handy hints

- For best results apply to light coloured & lightweight fabrics.
- Trim or cut apart designs to create custom looks.



### step 1

Prewash t-shirt – do not use fabric softener. Dry and iron.

### step 2

Preheat dry iron between wool and cotton setting – do not use steam. Lay t-shirt on hard, heat tolerant surface. Position Soft Transfer face down in desired location and pin corners in place to avoid movement during application. Apply heat evenly across design area by pressing one section at a time for 20-25 seconds. Allow project to cool to touch. Remove pins and carefully lift up transfer paper; if necessary replace and apply heat again.

### step 3

Using iron as above, position Flocked Iron-On Transfer face down in desired location. Press firmly for 20-25 seconds; allow project to cool to touch.

Carefully peel away transfer paper; if necessary replace and apply heat again.

Or, using iron as above, position Metallic Foil Transfer face down in desired location. Press firmly for 30-35 seconds; allow project to cool to touch. Carefully peel away transfer paper; if necessary replace and apply heat again.

### step 4

Preheat dry iron to cotton setting – do not use steam. Place Appliqué Patch design side up in desired position on t-shirt; cover with a pressing cloth. Press firmly for 10-15 seconds to tack appliqué in place. Turn t-shirt inside out and press the back of the appliqué patch firmly for 20-25 seconds. Allow project to cool to touch and check adhesiveness; if necessary press from the inside again.

